


## ENDURANCE INSTRUCTIONS





## **Lap Counter Instructions**

| Power On:           | Press and hold MAIN (round) button                                                                                |
|---------------------|-------------------------------------------------------------------------------------------------------------------|
| Set Number of Laps: | Press UP or DOWN buttons                                                                                          |
| Start Race:         | Press, hold MAIN button, release when countdown starts                                                            |
| Jump Start:         | If racer leaves before "Go", racer is penalized 1 lap                                                             |
| Reset:              | Press MAIN button once after race begins to start over<br>Press and hold MAIN button after finish to start at "0" |
| Race End:           | First to cross line displays trophy; second displays P2                                                           |
| Power Off:          | Power turns off after 5 minutes of no activity                                                                    |
| Flip Display:       | Press and hold UP and DOWN buttons to flip display 180 <sup>o</sup>                                               |

## **Battery Instructions**

- Install Batteries: Open battery panel on back of Lap Counter with phillips head screwdriver. Install new AAA batteries according to diagram.
- Make sure batteries are installed with correct polarity
- Do not short circuit supply terminals
- Do not mix different types of batteries or new and used batteries
- Rechargeable batteries must be removed from Lap Counter before recharging
- Do Not try to recharge Non-Rechargeable batteries
- Rechareable batteries must only be charged under adult supervision.
- Remove dead batteries immediately

